

CRG SERIE

Kurzanleitung



Einleitung

Diese Kurzanleitung beschreibt die Inbetriebnahme der servoelektrischen Greifmodule der CRG Serie. Sie ersetzt nicht die Betriebsanleitung.

👉 Die vollständige Betriebsanleitung finden Sie unter <https://www.weiss-robotics.com/crg>

Personalqualifikation

Die Montage, Erstinbetriebnahme, Wartung und Instandsetzung des Greifmoduls darf nur von geschultem Fachpersonal durchgeführt werden. Jede Person, die vom Betreiber mit Arbeiten am Greifmodul beauftragt ist, muss die Betriebsanleitung gelesen und verstanden haben.

Sicherheitsbewusstes Arbeiten

Beachten Sie die am Einsatzort gültigen Sicherheits- und Unfallverhütungsvorschriften.



- Keine Teile von Hand bewegen, wenn die Energieversorgung angeschlossen ist.
- Nicht in die offene Mechanik und den Bewegungsbereich des Greifmoduls greifen.
- Greifmodul vor allen Arbeiten stromlos setzen.

Hinweise auf besondere Gefahren



- Verletzungsgefahr durch herabfallende und herausschleudernde Gegenstände! Schutzeinrichtungen vorsehen.
- Verletzungsgefahr bei unerwarteten Bewegungen der Maschine/Anlage!

CRG SERIE

Kurzanleitung



Einleitung

Diese Kurzanleitung beschreibt die Inbetriebnahme der servoelektrischen Greifmodule der CRG Serie. Sie ersetzt nicht die Betriebsanleitung.

👉 Die vollständige Betriebsanleitung finden Sie unter <https://www.weiss-robotics.com/crg>

Personalqualifikation

Die Montage, Erstinbetriebnahme, Wartung und Instandsetzung des Greifmoduls darf nur von geschultem Fachpersonal durchgeführt werden. Jede Person, die vom Betreiber mit Arbeiten am Greifmodul beauftragt ist, muss die Betriebsanleitung gelesen und verstanden haben.

Sicherheitsbewusstes Arbeiten

Beachten Sie die am Einsatzort gültigen Sicherheits- und Unfallverhütungsvorschriften.



- Keine Teile von Hand bewegen, wenn die Energieversorgung angeschlossen ist.
- Nicht in die offene Mechanik und den Bewegungsbereich des Greifmoduls greifen.
- Greifmodul vor allen Arbeiten stromlos setzen.

Hinweise auf besondere Gefahren



- Verletzungsgefahr durch herabfallende und herausschleudernde Gegenstände! Schutzeinrichtungen vorsehen.
- Verletzungsgefahr bei unerwarteten Bewegungen der Maschine/Anlage!

CRG SERIE

Quick Start Guide



Introduction

This quick start guide describes the first steps with the CRG series servo-electric gripping modules. It does not replace the official operating manual for the CRG series.

 The complete operating manual can be found at <https://www.weiss-robotics.com/crg>

Target audience

The assembly, initial commissioning, maintenance and repair of the gripping module may be performed only by trained specialist personnel. Every person called upon by the operator to work on the gripping module must have read and understood the complete operating manual.

Safety Considerations

Please note the safety and accident prevention regulations that are valid at the operating site.



- Do not move any parts by hand if the power supply is connected.
- Do not reach into the open mechanics or the movement area of the gripping module.
- Remove electric power before working on the gripping module.

Notes on particular risks



- Risk of injury from objects falling and being ejected. The danger zone must be guarded during operation.
- Risk of injury during unexpected movements of the machine / system!

CRG SERIE

Quick Start Guide



Introduction

This quick start guide describes the first steps with the CRG series servo-electric gripping modules. It does not replace the official operating manual for the CRG series.

 The complete operating manual can be found at <https://www.weiss-robotics.com/crg>

Target audience

The assembly, initial commissioning, maintenance and repair of the gripping module may be performed only by trained specialist personnel. Every person called upon by the operator to work on the gripping module must have read and understood the complete operating manual.

Safety Considerations

Please note the safety and accident prevention regulations that are valid at the operating site.



- Do not move any parts by hand if the power supply is connected.
- Do not reach into the open mechanics or the movement area of the gripping module.
- Remove electric power before working on the gripping module.

Notes on particular risks



- Risk of injury from objects falling and being ejected. The danger zone must be guarded during operation.
- Risk of injury during unexpected movements of the machine / system!